

King Size Bed Assembly and Parts List:

Parts

1. Headboard
2. Footboard
3. (2) Side Rails
4. Roll of bed slats
5. Center Strut and (2) 5/16 x 1 1/2" machine screws
6. Center leg with (2) barrel nuts, (2) Allen head bolts and Allen wrench
7. (4) Bed bolts, nuts, washers and lock washers (for attaching rails to posts)
8. (8) bolt covers
9. Care Kit (wax, steel wool, care instructions)

Tools needed

Bed wrench (included)
Allen wrench (included)
#3 (Large) Phillips screwdriver
Medium slotted screwdriver

One person can perform the assembly but two make the job easier.

1. Stand the headboard up against the wall where bed is to be placed.
2. Position the 2 side rails on the floor so that the wood ledger strips that support the slats are toward the floor. (See diagram)
3. Insert a bolt through each of the holes on the outside face of the headboard posts. After the bolt is through the hole place a washer, lock washer, and loosely thread on a square nuts on each bolt. (Just 2 or 3 turns)
4. With 2 people each holding an end of the headboard and an end of a rail, fit the rails into the mortise slots in the head posts so that the bolt/nut assembly fits over the crosswise slot in the rail as before. Tighten the bolts with the bed wrench.
5. Now stand the footboard assembly at the end of the bed and lift the rails to attach the footboard as you did with the headboard.
6. Fully tighten up all the bolts. You can use a 5/8" open-end wrench to hold the nut while you tighten the bolt or a large screwdriver can be wedged into the recess containing the nut to stop its rotation. Tighten bolts as tight as you can.
7. With the supplied Allen wrench take the bolts out of center leg and insert them through the holes in the center strut and back into the holes in the center leg. Tighten the bolts.
8. Place this center leg assembly on the 2 steel angle brackets. (steel pins fit in bracket slots)
9. Installing slats: Before cutting the packing tape on the slat sets place one set of a slats on the center of felt covered ledger strip on the side rail and center strut. Cut the tape holding slats and unfold them to the end of the rails in both directions. The last slats at each end rest behind metal pins in the rails. Repeat for the other set of slats
10. There is a leveling adjuster in the bottom of the center leg, adjust if necessary to level slats.

If you have any questions call us at our workshop 718 852-4935 (M-F, 9-5) or our Showroom 212 620-4682 (M-Sat 10-6, Thursday until 8, Sun. 12-5)